



LINE OF SHOWER FLOOR TILE & MORTAR BED BY OTHERS.

ALT R230 REINFORCED MEMBRANE WATERPROOFING (TYP.)

(1) PLY ALT R230 THIXO MEMBRANE FLASHING EXTEND MINIMUM 2" (5 CM) ON OUTSIDE OF PREPARED & CLEANED DRAIN BOWL OR PIPE.

PREPARE, LEVEL & PATCH SUBSTRATE W/ ALT RS337 MORTAR AFTER PRIMING & PRIOR TO APPLICATION OF ALT R230 WATERPROOFING MEMBRANE (TYP.)

SET DRAIN FLANGE IN ALT RS337 MORTAR OR ACCEPTABLE MORTAR/GROUT BY OTHERS (TYP.)

4" (10cm)
(MIN.)

ALT R230 RESIN BEAD TYPICAL @ ALL MEMBRANE TERMINATION POINTS.

ACCEPTABLE DECK DRAIN ASSEMBLY-ADJUST COLLAR AS REQUIRED TO ASSURE TOP OF GRATE IS FLUSH W/ FINISHED FLOOR.. PREPARE DRAIN BOWL AS REQ'D. FOR R230 THIXO MEMBRANE APPLICATION.

NOTE:

APPLY SUPPLEMENTAL COAT OF ALT R230 RESIN OVER IN-PLACE CURED MEMBRANE & BROADCAST TO EXCESS W/KILN DRIED AGGREGATE TO PROVIDE PROTECTION/BONDING LAYER IN ALL AREAS TO RECEIVE MORTAR-SET TILE OR OVERBURDEN.



ALTERNATE SHOWER DRAIN FLASHING

DRAWING NO.:

D-2B

REVISION
0

ISSUE DATE
10-15-2014

SCALE
N.T.S.

DRAWN BY
ALT Global

AD_02B