# **ALT R230 Membrane** Waterproofing & Vehicular Surfacing Specification



# **Technical Data Sheet**

PART 3 EXECUTION

PART 1 GENERAL	
System:	Fully reinforced waterproofing and surfacing system for parking decks, ramps and other heavy duty
	traffic areas over occupied spaces or where a reinforced waterproofing membrane is required, and all
	other ancillary work including but not limited to installation of drain, penetration and perimeter
	flashings, sealants and metal work as specified.
Weather	Do not apply membrane during or with the threat of inclement weather. Application of cold liquid-
Restrictions:	applied membrane and surfacing may proceed while air temperature is between 32° F (0° C) and 95° F
	(35° C) for ALT primers, mortars and finishes or 23° F (-5° C) and 95° F (35° C) for ALT R230
	membrane, providing the substrate is a minimum of 5 degrees above the dew point temperature, clean
	and dry.
Waterproofing	Waterproofing Warranty: Provide 20-year standard manufacturer's warranty under provisions of this
Warranty:	section.
Surfacing	Surfacing Warranty: Provide 10-year material warranty under provisions of this section based on the
Warranty:	surfacing option selected.

Waterproofing Membrane:	Cold liquid-applied reinforced membrane with non-woven reinforcing fabric, for a finished dry film membrane thickness of .080 inch nominal per ply; slip-resistant aggregate and colored topcoat finish as selected by owner from manufacturer's standard palette of colors; conforming to ASTM C 836 Subject to compliance with requirements, provide ALT R230 resin for use in an adhered membrane waterproofing system.
Wearing layer & Surfacing:	Cold liquid-applied self-leveling waterproof wearing layer, aggregate surfacing, and colored abrasio
Flashing:	Cold liquid-applied membrane with a non-woven reinforcing fabric, for a finished dry film membrane thickness of .080 inch nominal per ply; integral color finish as selected by owner from manufacturer standard palette of colors; conforming to ASTM C 836. Subject to compliance with requirements provide ALT R230 Thixo resin for use in an adhered flashing membrane system.
Accessories:	Provide resin primers, additives, surfacing topcoats, and accessory products as required recommended by the Membrane Manufacturer.

# Preparation: All substrates must be free from gross irregularities, loose, unsound or foreign material such as dirt, ice, snow, water, grease, oil, release agents, lacquers, or any other condition that would be detrimental to adhesion of the primer and/or resin to the substrate. All traffic bearing surfaces

require scarifying, sandblasting or grinding to achieve a suitable substrate.

Substrate shall have maximum moisture content of six (6) percent or 75% relative humidity, and be prepared as required to provide adhesion of the membrane to substrate with minimum bond strength of 219 psi  $(1.5 \text{ N/mm}^2)$  on concrete for traffic surfacing applications. Determinations of bond strength and moisture content shall be performed periodically by the Contractor throughout the course of work.

#### Primer:

Prime all substrates as recommended or required by Membrane Manufacturer. Primer is required on asphalt, concrete, wood and metals. For other substrates, contact the Membrane Manufacturer for recommendations.

#### Concrete:

Apply two-component ALT Primer 276 with a lambswool roller.

Minimum consumption:  $0.037 \text{ kg/ft}^2 (0.4 \text{ kg/m}^2)$ 

Cure Time: Minimum of 45 minutes.

#### Metal:

Apply single-component ALT Metal Primer with a lambswool roller.

Minimum consumption:  $0.016 - 0.02 \text{ kg/ft}^2 (0.17 - 0.2 \text{ kg/m}^2)$ 

Minimum Cure Times:

1-hour minimum @ 86° F (30° C)

2-hours minimum @ 68° F (20° C)

3-hours minimum @ 50°F (10°C)

4-hours minimum @ 38°F (3°C)

\*Note: Consumption and yield or primer will vary depending upon smoothness and absorbency of the substrate.

#### Flashing:

Apply an even base layer of ALT R230 Thixo resin, work ALT Fleece reinforcement into the wet resin saturating from the bottom up removing trapped air using a lambswool roller. Apply supplemental ALT R230 resin directly over the fleece as required to complete saturation and allow to cure until solid.

Base Coat: Minimum consumption of 0.21 kg/ft<sup>2</sup> (2.3 kg/m<sup>2</sup>) Top Coat: Minimum consumption of 0.09 kg/ft<sup>2</sup> (1.0 kg/m<sup>2</sup>)

#### Laps/Seams:

Maintain a minimum 2-inch (5 cm) overlap at all side laps of adjacent fleece rows and 4-inch (10 cm) overlaps at butt laps, tie-ins and flashings (reinforcing and resin).

#### Curing:

ALT R230 membrane is rainproof after approximately 30-minutes, and can be walked-on or top coated with aesthetic and/or skid resistant surface topcoat in approximately 45-minutes.

## Main Deck Waterproofing:

Apply an even base layer of ALT R230 resin, work ALT Fleece reinforcement into the wet resin saturating from the bottom up removing trapped air using a lambswool roller. supplemental ALT R230 resin directly over the fleece as required to complete saturation and allow to cure until solid.

Base Coat: Minimum consumption of 0.21 kg/ft<sup>2</sup> (2.3 kg/m<sup>2</sup>) Top Coat: Minimum consumption of 0.09 kg/ft<sup>2</sup> (1.0 kg/m<sup>2</sup>)

#### Laps/Seams:

Maintain a minimum 2-inch (5 cm) overlap at all side laps of adjacent fleece rows and 4-inch (10 cm) overlaps at butt laps, tie-ins and flashings (reinforcing and resin).

#### Curing:

ALT R230 membrane is rainproof after approximately 30-minutes, and can be walked-on or top coated with aesthetic and/or skid resistant surface topcoat in approximately 45-minutes.

## Main Deck **Wearing Layer:**

Main deck wearing layer uses coarse grain aggregates to create a highly slip-resistant wearing surface. Aggregate is broadcast to excess for full coverage directly into the ALT RS337 Mortar while wet.

Quartz Aggregate: Approximate consumption of 0.46 kg/ft<sup>2</sup> (5.0 kg/m<sup>2</sup>) or 1.0 lbs/ft<sup>2</sup> Quartz Aggregate Sizes:

Crystal Quartz: 0.7 – 1.2mm Basalt: 0.5 - 1.2mm

Curing: ALT RS337 Mortar is rainproof after approximately 30-minutes, and can be walked-on and

Main Deck Wearing Layer: (cont.)	finish coated in approximately 1-hour. Prior to applying finish, remove excess aggregate from surface by broom, vacuum or oil-free blower.
(cont.)	Finish:
	Apply proprietary aesthetic surface topcoat. Apply an even topcoat of ALT Finish 288 resin using a hard rubber squeegee and lambswool roller at a minimum consumption of 0.07 kg/ft <sup>2</sup> (0.8 kg/m <sup>2</sup> ).
	Curing: ALT Finish is rainproof after approximately 30-minutes, and can be walked-on in approximately
	2-hours. ALT Finish should be applied within 12-hours of the ALT RS337 Mortar application.
Ramps, High Traffic Areas	For ramps, high traffic areas and turning radii, ALT RS337 Mortar uses in combination
& Turniing Radii:	with ALT R268 Textured Coating to create an extra heavy-duty slip-resistant wearing surface.
	Surfacing Layer:
	Apply an even layer of ALT R268 Textured Coating using a trowel. Back roll the wet resin
	using a clean ALT roller pre-wetted with ALT R268 Textured Coating for added texture.
	Wearing Coat: Minimum consumption of 0.33 kg/ft <sup>2</sup> (3.5 kg/m <sup>2</sup> )
	Curing:
	ALT R268 Textured Coating is rainproof and can be walked-on in approximately 15-minutes and can bear vehicular traffic in approximately 45-minutes.
Staging:	In a normal ALT R230 membrane application, flashings are installed first, followed by the application of the deck waterproofing, surfacing, aggregate and seal-coats.
	Work Interruptions:  If work is interrupted for more than 12-hours, use ALT Activator to reactivate the transition area. ALT Activator should be allowed a minimum of 20-minutes evaporation time after application, and over-coated within 60-minutes of application. Re-apply ALT Activator as required to assure proper reactivation of transition areas.
	Tie-ins: For all tie-in locations, provide a minimum overlap of 4 inches (10 cm), reinforcing fabric and resin.
Water Testing:	Prior to applying wearing layer, aggregate finish and seal-coat, flood test all horizontal applications with a minimum 2" (51 mm) head of water for 24 hours. Mark any leaks and repair when the membrane is dry. Before flood testing, be sure the structure will withstand the dead load of the water. For well-sloped decks, segment the flood test to avoid deep water near drains.
	Conduct the flood test after completing the ALT R230 membrane waterproofing application. Immediately after the flood test and all necessary repairs are made apply surfacing and finish.
Protection:	Upon completion of new work (including all associated work), institute appropriate procedures for surveillance and protection of finished work during remainder of construction period. Protect all areas where membrane has been installed.

#### **DISCLAIMER**

NO WARRANTY, EXPRESS OR IMPLIED, IS MADE IN THIS DOCUMENT. THE PRODUCT IS NOT CLAIMED TO BE MERCHANTABLE OR FIT FOR ANY PARTICULAR PURPOSE. User and certified ALT Global applicators determine suitability only. See individual ALT Global product data sheets, SDS sheets, guide specifications and details for complete information regarding the suitability, application and handling of ALT Global products.