



ALT R230 THIXO MEMBRANE FLASHING STRIP  
EXTEND ONTO PREPARED & PRIMED  
EXISTING ROOF TO REMAIN (TYP.)

FILL VOIDS BETWEEN NEW & EXISTING  
ROOF WITH ALT R290 PASTE OR  
ACCEPTABLE FILL MATERIAL (TYP.)

ACCEPTABLE RIGID ROOF INSULATION &  
OVERLAYMENT BOARD INFILL (ADHERED)

PREPARE, LEVEL & PATCH SUBSTRATE  
W/ ALT R290 PASTE OR RS242 MORTAR  
AFTER PRIMING & PRIOR TO APPLICATION  
OF ALT R230 MEMBRANE (TYP.)

ALT R230 FIELD MEMBRANE

FILL VOIDS AND ASSURE FLUSH TRANSITION  
@ VERTICAL EDGES OF INSULATION & OVER-  
LAYMENT BOARD W/ALT R290 PASTE (TYP.)

ALT R230 THIXO MEMBRANE TRANSITION  
ISOLATION FLASHING REQUIRED TO SEPARATE  
NEW & EXISTING ROOF ASSEMBLIES.

PRE-SATURATE EDGE OF ALT FLEECE  
REINFORCEMENT W/ALT R230 THIXO RESIN  
& TUCK INTO SAW-CUT REGLET.

ON MONOLITHIC CONCRETE DECKS PROVIDE  
1" MIN. DEEP SAW-CUT REGLET FOR TERMINATION  
OF ALT R230 MEMBRANE WATERPROOFING.

**NOTE:**  
TREATED WOOD BLOCKING OR STEEL ANGLE  
TRANSITION REQUIRED ON APPLICATIONS  
WHERE EXISTING ROOF MUST BE STABILIZED  
OR ADDITIONAL SECUREMENT IS REQUIRED.

DRAWING NO.:

**M-1E**

AM\_01E

**ISOLATION TIE-IN TO EXISTING INSULATED ROOF**

REVISION	0	ISSUE DATE	8-20-2014	SCALE	N.T.S.	DRAWN BY	ALT Global
----------	---	------------	-----------	-------	--------	----------	------------



**ALT**