



NOTE:
 APPLY TOPCOAT OF ALT R230 RESIN OVER CURED IN-PLACE MEMBRANE & BROADCAST TO REFUSAL WITH KILN-DRIED QUARTZ SILICA @ AREAS WHERE NEW MORTAR WILL CONTACT ALT R230 THIXO MEMBRANE.



THRU-WALL FLASHING REPAIR

DRAWING NO.:

B-1E

REVISION	ISSUE DATE	SCALE	DRAWN BY
0	10-15-2014	N.T.S.	ALT Global