



ACCEPTABLE DECK DRAIN ASSEMBLY-ADJUST COLLAR AS REQUIRED TO ASSURE TOP OF GRATE IS FLUSH W/ FINISHED FLOOR.. PREPARE DRAIN BOWL AS REQ'D. FOR R230 THIXO MEMBRANE APPLICATION.

NOTE:

APPLY SUPPLEMENTAL COAT OF ALT R230 RESIN OVER IN-PLACE CURED MEMBRANE & BROADCAST TO EXCESS W/KILN DRIED AGGREGATE TO PROVIDE PROTECTION/BONDING LAYER IN ALL AREAS TO RECEIVE MORTAR-SET TILE OR OVERBURDEN.



SHOWER DRAIN FLASHING

DRAWING NO.:

D-2A

REVISION
0

ISSUE DATE
10-15-2014

SCALE
N.T.S.

DRAWN BY
ALT Global

AD_02A