



ACCEPTABLE ALT TRAFFIC SURFACING  
SEE SPECIFICATION FOR OPTIONS.

ALT R230 REINFORCED MEMBRANE  
EXTEND TO EDGE OF DRAIN.

(1) PLY ALT R230 MEMBRANE FLASHING  
EXTEND MINIMUM 2" (5 CM) INTO  
PREPARED & CLEANED DRAIN BOWL.

PREPARE, LEVEL & PATCH SUBSTRATE  
W/ALT RS242 MORTAR AFTER PRIMING &  
PRIOR TO APPLICATION OF ALT R230  
WATERPROOFING MEMBRANE (TYP.)

SET DRAIN FLANGE IN ALT RS242 MORTAR  
AS REQUIRED TO DEVELOP A SMOOTH  
TRANSITION (TYP.)

4" (10cm)  
(MIN.)

ALT R230 RESIN BEAD TYPICAL @ ALL  
MEMBRANE TERMINATION POINTS.

ACCEPTABLE DECK DRAIN ASSEMBLY-ADJUST  
COLLAR AS REQUIRED TO ASSURE TOP OF  
GRATE IS FLUSH W/TRAFFIC SURFACE.  
PREPARE DRAIN BOWL AS REQ'D. FOR  
R230 MEMBRANE APPLICATION.



**TYPICAL TRAFFIC DECK DRAIN**

DRAWING NO.:

**TR-D1**

REVISION  
0

ISSUE DATE  
10-15-2014

SCALE  
N.T.S.

DRAWN BY  
ALT Global

TR\_D01