

TIE-IN TO NON-COMPATIBLE ROOF

DRAWN BY
ALT Global

SCALE
N.T.S.

ISSUE DATE
10-15-2014

REVISION
0



NOTE:

THIS FLASHING DETAIL DOES NOT WARRANT AGAINST LEAKS THAT MAY OCCUR DUE TO WATER INFILTRATION THROUGH THE EXISTING ROOF SYSTEM TO REMAIN OR MATERIALS BY OTHERS.

FILL VOID BEHIND ALT R230 MEMBRANE W/ ALT R290 PASTE OR ALT RS242 MORTAR AS REQUIRED.

ALT R230 FIELD MEMBRANE-PRESATURATE EDGE OF FLEECE W/RESIN & TUCK INTO 1" MIN. DEEP SAW-CUT REGLET

ACCEPTABLE MEMBRANE SPLICE STRIP BONDED TO NEW ALT R230 MEMBRANE & EXISTING ROOF MEMBRANE IN AN APPROVED MANNER (BY OTHERS)

ALT R230 FIELD MEMBRANE APPLIED TO STRUCTURAL CONCRETE SUBSTRATE

PREPARE, LEVEL & PATCH SUBSTRATE W/ ALT R290 PASTE OR RS242 MORTAR AFTER PRIMING & PRIOR TO APPLYING ALT R230 MEMBRANE (TYP.)

LINE OF EXISTING MEMBRANE TO BE CLEANLY CUT & REMOVED AS REQUIRED.

EXISTING MEMBRANE TO REMAIN. CLEAN & PREPARE AREA OF TIE-IN AS REQUIRED TO PROMOTE SOUND & WATERTIGHT BOND W/ MEMBRANE SPLICE STRIP BY OTHERS.

NOTE: EXISTING ROOF MEMBRANE SHOULD BE FULLY BONDED & INTACT FOR PROPER TIE-IN (TYP.)

