



- ALT R230 THIXO MEMBRANE FLASHING STRIP EXTEND ONTO PREPARED & PRIMED EXISTING ROOF TO REMAIN (TYP.)
- FILL VOIDS BETWEEN NEW & EXISTING ROOF WITH ALT R290 PASTE OR ACCEPTABLE FILL MATERIAL (TYP.)
- ACCEPTABLE RIGID ROOF INSULATION & OVERLAYMENT BOARD INFILL (ADHERED)
- PREPARE, LEVEL & PATCH SUBSTRATE W/ ALT R290 PASTE OR RS242 MORTAR AFTER PRIMING & PRIOR TO APPLICATION OF ALT R230 MEMBRANE (TYP.)
- ALT R230 FIELD MEMBRANE

- FILL VOIDS AND ASSURE FLUSH TRANSITION @ VERTICAL EDGES OF INSULATION & OVERLAYMENT BOARD W/ALT R290 PASTE (TYP.)
- ALT R230 THIXO MEMBRANE TRANSITION ISOLATION FLASHING REQUIRED TO SEPARATE NEW & EXISTING ROOF ASSEMBLIES.
- PRE-SATURATE EDGE OF ALT FLEECE REINFORCEMENT W/ALT R230 THIXO RESIN & TUCK INTO SAW-CUT REGLET.
- ON MONOLITHIC CONCRETE DECKS PROVIDE 1" MIN. DEEP SAW-CUT REGLET FOR TERMINATION OF ALT R230 MEMBRANE WATERPROOFING.

NOTE:
 TREATED WOOD BLOCKING OR STEEL ANGLE TRANSITION REQUIRED ON APPLICATIONS WHERE EXISTING ROOF MUST BE STABILIZED OR ADDITIONAL SECUREMENT IS REQUIRED.

ISOLATION TIE-IN TO EXISTING INSULATED ROOF		DRAWN BY	ALT Global
REVISION	0	SCALE	N.T.S.
ISSUE DATE	8-20-2014		