


FRONT VIEW



ALT R230 RESIN BEAD TYPICAL @ ALL MEMBRANE TERMINATION POINTS.

APPLY APPROVED SEALANT BETWEEN DOOR FRAME & ALT R230 THIXO MEMBRANE AS REQUIRED (BY OTHERS)

METAL SILL FLASHING SET IN BED OF SEALANT (BY OTHERS)

REMOVE FRAME AS REQUIRED. APPLY ALT R230 THIXO MEMBRANE ONTO WALL OPENING JAMBS & TERMINATE BEHIND DOOR FRAME.

REMOVE SILL PLATE, EXTEND ALT R230 THIXO MEMBRANE FULL DEPTH OF SILL & RESET SILL PLATE IN A FULL BED OF APPROVED SEALANT OR WATER CUT-OFF MASTIC.

ALUMINUM KICK-PLATE TO PROTECT EDGE OF MEMBRANE (BY OTHERS)

ASSURE FULL RESIN SATURATION OF FLEECE & CONTACT W/SUBSTRATE.

ALT R230 FIELD MEMBRANE

PREPARE, LEVEL & PATCH SUBSTRATE AS REQUIRED W/APPROVED LEVELING COMPOUND AFTER PRIMING & BEFORE APPLYING ALT R230 MEMBRANE (TYP.)

2" (5cm) MINIMUM
OR AS REQD. TO
MATCH HEIGHT OF
WALL FLASHING

4" (10cm)
(MIN.)

DRAWING NO.:

M-2C

AM_02C

TYPICAL DOOR SILL FLASHING

DRAWN BY
ALT Global

SCALE
N.T.S.

ISSUE DATE
10-15-2014

REVISION
0



ALT