



ALT R230 THIXO MEMBRANE FLASHING STRIP
EXTEND ONTO PREPARED & PRIMED
EXISTING ROOF TO REMAIN (TYP.)

FILL VOIDS BETWEEN NEW & EXISTING
ROOF WITH ALT R290 PASTE OR
ACCEPTABLE FILL MATERIAL (TYP.)

ACCEPTABLE RIGID ROOF INSULATION &
OVERLAYMENT BOARD INFILL (ADHERED)

PREPARE, LEVEL & PATCH SUBSTRATE
W/ ALT R290 PASTE OR RS242 MORTAR
AFTER PRIMING & PRIOR TO APPLICATION
OF ALT R230 MEMBRANE (TYP.)

ALT R230 FIELD MEMBRANE

FILL VOIDS AND ASSURE FLUSH TRANSITION
@ VERTICAL EDGES OF INSULATION & OVER-
LAYMENT BOARD W/ALT R290 PASTE (TYP.)

ALT R230 THIXO MEMBRANE TRANSITION
ISOLATION FLASHING REQUIRED TO SEPARATE
NEW & EXISTING ROOF ASSEMBLIES.

PRE-SATURATE EDGE OF ALT FLEECE
REINFORCEMENT W/ALT R230 THIXO RESIN
& TUCK INTO SAW-CUT REGLET.

ON MONOLITHIC CONCRETE DECKS PROVIDE
1" MIN. DEEP SAW-CUT REGLET FOR TERMINATION
OF ALT R230 MEMBRANE WATERPROOFING.

NOTE:
TREATED WOOD BLOCKING OR STEEL ANGLE
TRANSITION REQUIRED ON APPLICATIONS
WHERE EXISTING ROOF MUST BE STABILIZED
OR ADDITIONAL SECUREMENT IS REQUIRED.

DRAWING NO.:

M-1E

AM_01E

ISOLATION TIE-IN TO EXISTING INSULATED ROOF

REVISION	0	ISSUE DATE	8-20-2014	SCALE	N.T.S.	DRAWN BY	ALT Global
----------	---	------------	-----------	-------	--------	----------	------------

